



11" ELECTRIC HealthGrill



 **imarflex**[®]
In Every Home.
www.imarflex.com

AHG-1125

SPECIFICATION

MODEL NO. : AHG-1125
RATED VOLTAGE : 230Va.c. 60Hz
POWER CONSUMPTION : 850 watts


IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions carefully.
2. Before using the unit, check if the voltage indicated corresponds with the convenience outlet (230Va.c.).
3. Do not use any appliance with a damaged cord or plug. If the cord is damaged, it should be replaced with the same type and size or bring the unit to the nearest Imarflex Authorized Service Center.
4. Do not use two-way socket with another appliance.
5. To protect against electric shock, do not immerse the Griddle Plate and Thermostat Control in water.
6. Children should be supervised to ensure that they do not play with the appliance.
7. This appliance is not intended to use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
8. Do not use accessories not recommended or sold with this unit.
9. Keep curtains, furniture, flammable materials, etc. away from the unit and from the convenience outlet where the unit is plugged.
10. Extreme caution must be taken in moving an appliance containing hot oil or liquids.
11. Do not touch the Griddle Plate while cooking is in progress.
12. Do not use metal scouring in cleaning the unit.
13. Do not use this unit other than its intended use.
14. CAUTION: Never leave the unit unattended while cooking.
15. ***For household use only, not intended for any business purposes.***
16. Save this instruction for future reference.




DESCRIPTION OF PARTS




HOW TO USE

1. Insert the Griddle Plate into Base by aligning the Plate Socket unto the base hole and push down the Griddle Plate.
2. Insert the Thermostat Control on the Plate Socket, ensuring that it is set to “OFF” position then plug the unit into the convenience outlet.




3. Adjust the Thermostat Control according to your cooking requirement (Note: Use medium to low heat for best cooking result, very high temperatures can cause discoloration and shorten the life span of any non-stick surface. If higher temperatures are necessary, preheat on medium heat for a few minutes).



TEMPERATURE
190 °C
150 °C
120 °C
90 °C

4. When the Griddle Plate reaches the required temperature, the power light indicator will turn off.
5. Put the food in Griddle Plate.
6. Once the food is cooked, remove it from the Griddle Plate.
7. Turn OFF and unplug after use.



CLEANING AND MAINTENANCE

1. Always unplug the unit from the convenience outlet and allow to cool before putting ON or taking OFF parts and before cleaning.
2. Wash the Griddle Plate with soap and water using sponge (Do not allow bottom part to get wet). Wipe it dry.
3. Do not use abrasive materials to avoid scratches.
4. Do not immerse the Griddle Plate and Thermostat Control in water.
5. Base is washable with soap and water.

REMINDER: Please do not forget to fill up and send the warranty card.