

FOR WARRANTY REGISTRATION PLEASE
CLICK THIS LINK: <https://rb.gy/7b8cmw>

FOR SERVICE CENTERS PLEASE
CLICK THIS LINK: <https://rb.gy/senj28>



4 in 1 MULTI-COOKER

Rice Cooker • Shabu-shabu • Steamer • Warmer



STAINLESS STEEL
POT & STEAMER

1.5 LITERS
CAPACITY



500W
POWER

FOR HOUSEHOLD USE ONLY

imartec® Corporation

IRC-15LS

SPECIFICATION:

MODEL NO.	:	IRC-15LS
RATED VOLTAGE	:	230Va.c. 60Hz
POWER CONSUMPTION	:	500W
BOX DIMENSION	:	268*268*272mm
UNIT DIMENSION	:	250*280*296mm
GROSS WEIGHT	:	2.49kg.
UNIT WEIGHT	:	2.14kg.

IMPORTANT SAFEGUARD:

1. Read all instructions carefully.
2. Before using the unit, check if the voltage indicated corresponds with the convenience outlet (230Va.c.).
3. Do not use two-way socket with another appliance.
4. Do not use any appliance with a damaged cord or plug. If the cord is damaged it should be replaced with the same type and size or bring the unit to the nearest authorized service center.
5. Do not place the unit near a gas stove, an electric burner, in a heated oven.
6. Place the unit on a stable surface; keep it away from the edge of the counter to avoid accidents.
7. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliances by a person responsible for their safety.
8. Children should be supervised to ensure that they do not play with the appliance.
9. Extreme caution must be exercised when using an appliance containing hot water in the rice cooker when boiling.
10. Do not allow the cord to touch the hot surface of the unit.
11. For protection against electric shock, do not immerse the unit including the power base in water or any other liquid.
12. Always ensure that the lid is closed and do not lift it while the water in the multi-cooker is boiling. Scalding may occur if the lid is removed during the cooking cycle. Do not touch the hot surfaces of the rice cooker.
13. Allow the unit to cool down before cleaning.
14. Not intended for outdoor use.
15. No parts are dishwasher safe.
16. Do not cook food below the recommended minimum level (2 cups) or above the maximum level (8 cups). Boiling water may come out of the rice cooker.
17. Carry or move the multi-cooker only by its handle.
18. In case of malfunction, please bring the rice cooker to the nearest Authorized Imarflex Service Center.
19. Avoid water spillage into the socket, connector, cord and alike.
20. Rice cooker body may get very hot, be careful when handling.
21. Use of accessories or equipment not supplied by the manufacturer may cause damage or malfunctioning of your appliance or result in injuries.
22. ***For household use only, not intended for any business purposes.***
23. Do not use this unit other than its intended use.
24. CAUTION: In order to avoid a hazard due to inadvertent resetting of the thermal cutout, this appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by the utility.

DESCRIPTION OF PARTS:



HOW TO USE:

I - RICE COOKING

1. Put the rice into the inner pot, measure the desired amount of rice using the measuring cup supplied with the unit.
2. Wash the rice several times until the water is relatively clear.
3. Measure water on rice for cooking.
 - One cup of rice measures 0.16L (160ml)
 - Use water line inside the pot as a cooking guide. The right line corresponds to the cup capacity of the uncooked rice, the left line corresponds to the liter capacity of the water
 - The water line on the inner pot cannot be used for cooking congee, you can add more or less water depending on your taste or preference
 - Do not cook food below the recommended minimum level (2 cups) or above the maximum level (8 cups). Boiling water may come out of the rice cooker
4. Wipe the bottom part of the inner pot and put it inside the unit, turn it slightly from left to right to ensure that the pot is properly fit into the heater plate, and then level the rice.
 - Do not heat the inner pot on the top of the stove, otherwise, it will be deformed by the high temperature. Use only the pot supplied with the unit.
5. Plug the unit into the convenience outlet when you're ready to cook rice.
6. Press down the switch. Cook light indicator will lights up and rice will start to cook.
 - If the switch knob failed to push down, the "warm" light will turn ON, the rice will not be cooked
7. When it's done, the switch will pop-up and a click sound will be heard, and the warm light indicator will light up.
 - After the cooking cycle, keep the cover closed for about 10 minutes to make the rice fluffier
8. Use only the spatula supplied with the unit to avoid scratches.
9. Unplug the unit after every use.

II – FOOD WARMING

1. Place food inside inner pot or leave cooked rice in the inner pot.
2. Leave the unit in "warm" position.

III – STEAMING

1. Put water in the inner pot.
2. Place steamer pan on top of the inner pot.
3. Arrange food for steaming inside the steamer pan and cover it.
4. Plug the cord into the convenience outlet and press down the switch to start cooking.

IV – SHABU-SHABU

1. Simply place the inner pot inside the rice cooker.

2. Fill the pot with the desired amount of water or soup base for SHABU-SHABU.
3. Move the selector into RICE COOKING.
4. Press down the switch (cook light indicator will turn ON).
5. Let it boil.
6. Put all the ingredients and seasoning.
7. Lift up the switch to turn the unit to keep warm.
8. Unplug to turn OFF.

CLEANING AND MAINTENANCE:

1. Always unplug the unit before cleaning. Make sure that the unit temperature cools down before cleaning. Do not clean when it is still hot.
2. To protect from electrical hazards, do not immerse the unit and electric cord in water.
3. Tempered glass lid, steamer, spatula, and inner pot are washable with soap and water.
4. Keep the bottom part of the inner pot and heater plate clean.
5. Do not use abrasive materials to avoid scratches.
6. Wipe the body with damp cloth.
7. Grains of rice or residues may adhere to the heater plate. Make sure that the heater plate is free from residues.

TROUBLE SHOOTING:

TROUBLES	CAUSES	REMEDY
1. The pilot light is OFF: Heating Plate is not hot.	1. Cooker is not properly connected to the convenience outlet. 2. The lights or resistance are loose or busted.	1. Check the switch, outlet, fuse, power cord and plug it properly. 2. Bring the unit to nearest authorized service center.
2. The rice is half-cooked or cooking time is too long.	1. Not enough water. 2. Heater plate maybe deformed. 3. Inner pot maybe deformed. 4. Dirt in between Inner Pot and Heater.	1. Add more water. 2. Turn the Inner Pot slightly from left to right to ensure that the pot is properly fitted into the Heater Plate. 3. Polish the dirt with sand paper. 4. Bring the unit to nearest authorized service center.
3. The bottom part of the cooked rice is brown.	1. Thermostat is malfunctioning.	1. Bring the unit to nearest authorized service center.
4. The switch doesn't automatically switch to keep warm.	1. The warm thermostat is malfunctioning.	1. Bring the unit to nearest authorized service center.
5. Grounded Body.	1. Soup might have flow to the plug or electrical parts, making the insulation resistance fall.	1. Bring the unit to nearest authorized service center.

REMINDER: Please do not forget to register your product warranty through the warranty registration website at <https://imarflex.ph>

Distributed By: Evergood Unlimited Corp.
901 G.Masangkay St., Manila
Made in China